



# Stabilized Construction Entrance

MS4-EDU-07 · Field guide for applicants and contractors



| Item            | Minimum                                   |
|-----------------|-------------------------------------------|
| Width           | 20 feet minimum, clear                    |
| Length          | 50 feet minimum, back from the paved road |
| Stone depth     | 6 inches minimum                          |
| Stone           | 2 to 4 inch, No. 2 or No. 3               |
| Under the stone | Filter fabric, recommended                |

## Install It

- Give the pad at least 20 feet of clear width.
- Run it at least 50 feet back from the paved road.
- Place the stone at least 6 inches deep.
- Filter fabric under the stone is recommended.

## Keep It Working

- Inspect after rain, and when ruts show.
- Add rock when the pad thins or soil shows.
- Take sediment off the pad.
- Sweep or scrape mud off the road.

**Sweep or scrape tracked mud. Never wash sediment into a storm drain!**